

V, VA, VR, RFL-series, air valves and accessories



To control and regulate air supply

Accessory valves provide greater safety and more efficient clamping cycles

Recommended for use with all air powered units

Directional valves to control booster and pump air supply

Remote air valve permits either hand or foot operation

Maximum Air Pressure bar	Ports NPTF	Model Number 5-way, 2-pos manual directional valve	Model Number 5-way, 2- pos 120 VAC solenoid directional valve	Model Number Rapid Exhaust valve	Model Number Air Check valve	Model Number Regulator-Filter- Lubricator
2 - 10	3/8"- 18	VA42	VAS42	-	-	-
0 - 7	3/8"- 18	-	-	VR-3	V-19	-
0 - 9	3/8"- 18	-	-	-	-	RFL102